

我要—PASS



質 量 更 高 務 服 更 好

一年免費升級服務

<http://www.51-pass.com>

Exam : D-VXR-DY-01

Title : Dell VxRail Deploy Exam

Version : DEMO

1.Which two iDRAC settings must be set before running the VxRail Deployment Wizard? (Choose two.)

- A. Channel Privilege Level Limit to Operator
- B. NIC selection to Dedicated
- C. Auto Negotiation to Off
- D. Enable IPMI over LAN to Enabled

Answer: BD

2.What is the minimum and maximum number of nodes that can be selected to create a standard VxRail cluster in the deployment wizard?

- A. 2 and 12
- B. 2 and 32
- C. 3 and 6
- D. 3 and 64

Answer: C

3.Which three actions cause a host “Incompatible” message to be displayed when expanding an OSA VxRail cluster? (Choose three.)

- A. Adding a host with VxRail code 7.0.411 to a cluster with VxRail code 8.0.200
- B. Adding a host with an AMD CPU to a cluster with Intel CPUs.
- C. Adding a host with all NVMe SSDs to a cluster with all SAS SSDs
- D. Adding a host with all SSDs to a cluster with HDDs
- E. Adding a host with only 1 GbE NICs to a cluster with 10 GbE NICs

Answer: ABE

4.When following Dell best practices, what are two options for correctly installing VxRail nodes in a rack considering serial number order? (Choose two.)

- A. Start from the bottom of the rack, ordered by serial number from highest to lowest.
- B. Start from the bottom of the rack, ordered by serial number from lowest to highest.
- C. Start from the upper portion of the rack, ordered by serial number from lowest to highest.
- D. Start from the upper portion of the rack, ordered by serial number from highest to lowest.

Answer: BC

5.Refer to the exhibit.



Which selection in the VxRail deployment wizard leads to the displayed locked option?

- A. Customer-managed vCenter Server
- B. vSAN 2-Node Cluster
- C. Stretched Cluster
- D. VxRail-managed vCenter Server

Answer: D